



\*THIS FOOTER DIAGRAM IS FOR STANDARD PRODUCT ONLY  
 \*FOR PIER SPACING REFER TO SET UP MANUAL

- MWM** MARRIAGE WALL PIER
- W** WATER INLET
- D** DRAIN
- E** ELECTRICAL DROP
- DP** DOOR PIER
- DP** DOOR PIER
- REGULAR PIER**